

Trap-Eze™ Disposable Plaster Traps



Sanitary, convenient solutions for the capture and disposal of wet model trimming waste

- Economical trap systems designed to slow water discharge flow rate and allow plaster sediment to settle out of waste water
- No permanent traps to clean or messy liners to replace
- Fast and easy installation and trap replacement
- Made in the USA

New!

Trap-Eze BT Bottle Trap

The new Trap-Eze BT provides a convenient and easy to use bottle-style trap for permanent plumbing into the existing sanitary drain beneath the lab sink. The replaceable bottles feature excellent capacity for smaller labs and dental offices and are fast and easy to replace.

- Complete kit provides instructions and customizable 1 1/2" size plumbing and connectors for convenient hard-plumbing (requires a minimum 16" of height between the centerline of the sewer tail pipe and the floor of the cabinet)
- Complete system includes a 64 oz standard size clear plastic bottle, a pre-assembled trap body, and the plumbing connections typically required to fit the plumbing used in most dental office and dental lab sub-sink areas.



Buffalo# Description

62150	Trap-Eze BT Bottle Trap Complete System including 64 Oz. Plastic Bottle + 1 1/2" Piping Installation Kit
62155	Replacement Clear 64 Oz. Trap-Eze BT Plastic Bottles with Lids, Pkg. of 2

New!

Trap-Eze SS Self-Sanitizing Trap

Original classic Trap-Eze upgraded to include an automatic sanitizing system to keep it smelling fresh and clean

- New **patent-pending** sanitizing system inside the trap designed to last for months
- Fully automatic dispensing helps assure steady action and long term freshness
- Unique system covers the sanitizing agent and activates after the trap is in use

Buffalo# Description

Sanitrap1	3 1/2 Gallon Trap-Eze SS Complete Kit
Sanitrap2	3 1/2 Gallon Trap-Eze SS Refill (Sealed Bucket Only)

Buffalo# Description

Sanitrap3	5 Gallon Trap-Eze Complete Kit
Sanitrap4	5 Gallon Trap-Eze SS Refill (Sealed Bucket Only)

Made in USA



Original Classic Trap-Eze Disposable Trap

- Requires minimum 9" clearance between bottom of sink tail pipe and top of trap bucket for easy installation without tools
- All trap buckets feature high-strength plastic construction and permanently-sealed lids
- 3 1/2 gallon size (12 1/2" diameter x 11" H) ideal for intermediate applications
- 5 gallon size (12 1/2" diameter x 14 1/2" H) best for larger offices and labs with higher volume collection needs (space permitting)
- Two flexible hoses (1 1/2" ID x 1 3/4" OD x 20" long) conveniently connect trap to sink tail pipe and sewer tail pipe
- Flexible adaptor fitting for sewer tail pipe included for improved drain seal
- Complete kit includes sealed trap bucket, 2 hoses, and sewer tail pipe adapter fitting
- Refill includes trap and two plastic caps for sealing full trap

Buffalo# Description

62100	3 1/2 Gallon Trap-Eze Complete Kit
62106	3 1/2 Gallon Trap-Eze Refill (Sealed Trap Bucket Only)

Buffalo# Description

62110	5 Gallon Trap-Eze Complete Kit
62112	5 Gallon Trap-Eze Refill (Sealed Trap Bucket Only)

62108 Flexible Hoses Only for Trap-Eze, Set of 2 (18" Overall Length Each)

62100FIT Flexible Adaptor Fitting for Sewer Tail Pipe

Buffalo Dental Manufacturing Co., Inc.,

129 Lafayette Dr., PO Box 678, Syosset, NY 11791-0678 USA

Tel: 516.496.7200 or 800.828.0203 Fax: 516.496.7751

www.buffalodental.com

562100 0705

Please order today from your favorite Dealer!